

Fig. 1 Alternator Battery Disconnect Switch - One Wire Wiring Method
NOTE: Switches are not sensitive to input and output




Fig. 2 Alternator Battery Disconnect Switch - Field Alternator Wiring Method
NOTE: Switches are not sensitive to input and output